
Con. 2791-08.


(REVISED COURSE)

(3 Hours)



Attempt any four questions from remaining six questions.

(3) Assume suitable data wherever necessary.



(a) Why Tuning is required in PID controllers?


(b) Why PID controllers are not used in feed-forward controllers ?

(c) Define degrees of freedom. Find Degrees of freedom for Stirred Tank Heater System.

(d) Why systems with dead time are difficult to control ?

(e) Develop a feedback control system for STH system.

For a following graph find the output of Single speed Floating control mode action .



- (a) What are the steps involved in Designing/Selecting Estimator in inferential control ? Why inferential control is used.
 - (b) What is Gain Margin and Phase Margin? Explain Ziegler Nichols method in detail, 10
- 3. (a) A PI conrroller indicates an o/p of 12 mA when the error is zero. The setpoints is 10 suddenly increased to 14 mA. and controller o/p is recorded and is given below :

Time t, sec	0	10	20	30
o/p mA	14	16	18	20


- (b) Prove that proportional controller Introduces offset in the first order process. Consider 10 measurement gain and final control element. Gain equal to unity.
- (a) Develop a mathematical model for two Tank interacting capacities. 10
- (b) Develop a Electronic PID controller. 10
- (a) Explain Inverse Response concept with an example. 10 (b) Give an example of Batch process. Explain-10 (i) Recipe (ii) Grade (iii) Unit.

Marks: 100

20

- (a) Explain Internal Architecture of PLC. Why PC Interface and Real time Clock Circuit is 10 required in PLC?
 - (b) What is the objective of Adapative Control System ? Explain MRAC system (Model 10 Referenced Adapative Control)
- 7. (a) Develop a ladder logic program for a following system.

10



TSH— Temperature Switch High (Limit switch)
LSH_a, LSH_b, LSH—Level Switch High for storage tank and two tanks
RLY1—Relay for controlling Heater (ON-OFF)
SOV1, SOV2,— Solenoid valve 1 and 2.

of talling whith Stage stag former tank one of no renemal.

Start and stop button is used for starting and stopping the process.

When LSH is reached pump 1 is stopped and Heating is started. When TSH is reached heating is stopped through Relay Rly1 and Pump 2 is started at same time SOV 1 is started when LSHa is reached SOV1 is stopped and SOV2 is started when LSHb is reached SOV2 and Pump 2 are stopped.

(b) Explain why cascade control is preferred in CSTR over f/b control system. Draw any two other examples of CSTR.